TV / Cable Controls

The remote controls both the cable box and television therefore it is important that these instructions are followed otherwise the two devises will be put out of sync

AIM REMOTE AT TV AND CABLE BOX

To watch cable

- Turn on television (VAZIO logo turns white or red dot on TV) and cable box (Φ will appear on cable box) by pressing the **System ON** button.
- Press **VIDEO SOURCE**, select **HDMI 2 / CABLE**
- To turn both off press **System OFF** button.
- To view full channel listings, press GUIDE button

To watch a DVD

- To watch a DVD, switch on DVD with separate remote.
- Press **TV** button, then press **VIDEO SOURCE** and select **AV1**.

To watch movies on media player (TVX)

- To watch a movie on the media player, turn on media player with remote called TVX. Takes 2 minutes to boot up.
- Press **TV** button, then press **VIDEO SOURCE** and select **HDMI 1**.
- To return to watching cable, press **VIDEO SOURCE** and select **HDMI 2**.

PLEASE REMEMBER TO TURN TV OFF
To switch off TV, press **System OFF**.

- Parental lock for restricted viewing is **7762**

TV	**HDMI 2 / CABLE**
Media player	**HDMI 1**
DVD	**AV1**

Video source

Bedroom TV's

There is a television in every bedroom. Each receives a standard TV package from Brighthouse Networks (approx 100 channels).

All bedrooms have a digital box. Turn on TV with **TV** button and then turn on digital box with **DTA** button.

Scan thru channels using **CH+** and **CH-** buttons

Unfortunately there is no guide / channel list on the TV for the digital decorder. Please see channel list below.

basic & standard channels specific to county

ORANGE, OSCEOLA, SEMINOLE

2	WUCF PBS HD
3	WOFL FOX HD
4	WESH NBC HD
5	WKMG CBS HD
6	WRBW MyTV HD
7	WFTV ABC HD
15	WDSC HD
16	WOPX ION HD
20	WGN America
21	QVC
49	Bright House Networks 49
198	Vision TV (Orange only)
199	Government/Education
200	Government Access (Ocoee only)

basic & standard channels all counties

2-7	See specific to county	113	Bright House Sports Network
8	WKCF CW HD	143	Investigation Discovery
9	See specific to county	195	C-SPAN
10	WRDQ HD	196	C-SPAN2
11	TNT HD	197	C-SPAN3
12	TBS HD	455	WEFS
13	News 13 HD	456	WEFS Classic Arts
14	WACX	457	WEFS NASA Education
15-16	See specific to county	458	WEFS Florida Channel
17	WOTF UniMás HD	459	WDSC-ED
18	WVEN Univision HD	460	WDSC MHz Worldview
19	WTGL Good Life	462	WOTF GetTV
20-21	See specific to county	463	WKMG Live Well Network
22	WHLV TBN	464	WKCF Estrella TV
23	HLN	465	WRDQ Antenna TV
24	CNN HD	466	WKCF This TV
25	CNBC	468	WESH Me-TV
26	MSNBC	469	WFTV Mega TV
27	The Weather Channel	470	WUCF PBS HD
28	Fox News HD	471	WUCF Create
29	ESPN HD	472	WUCF UCF/World
30	ESPN2 HD	473	WUCF V-me
31	Sun Sports	911	WFTV Mega TV
32	Fox Sports 1	1013	News 13 HD
34	Nickelodeon HD	1016	WOPX ION HD
35	Disney Channel HD	1018	WVEN Univision HD
36	Cartoon Network HD	1020	WESH NBC HD
37	WE tv	1024	WUCF PBS HD
38	TV Land	1027	WRDQ HD
39	USA HD	1035	WOFL HD
40	Lifetime	1050	WDSC HD
41	Discovery HD	1060	WKMG CBS HD
42	A&E HD	1065	WRBW MyTV HD
43	History HD	1080	WKCF CW HD
44	Animal Planet HD	1090	WFTV ABC HD
45	TLC HD	1102	Nickleodeon HD
46	TCM	1105	Disney Channel HD
47	Bright House Sports Network	1122	Hallmark Channel HD
48	AMC HD	1127	ESPN HD
49	See specific to county	1128	ESPN2 HD
50	Fox Sports Florida	1154	Golf Channel HD
51	Hallmark Channel HD	1214	Fox News HD
55	LMN HD	1215	CNN HD
56	Travel Channel HD	1218	MSNBC HD
57	Bravo HD	1236	TBS HD
58	Golf Channel HD	1237	TNT HD
59	Food Network HD	1238	USA HD
60	truTV	1239	A&E HD
61	HGTV HD	1242	History HD
62	WTMO Telemundo	1250	HGTV HD
64	Oxygen	1252	Food Network HD
65	E!	1255	TLC HD
66	Comedy Central HD	1256	Discovery HD
67	BET	1259	Animal Planet HD
68	Spike HD	1267	Travel Channel HD
69	Syfy HD	1282	Cartoon Network HD
70	FX HD	1283	FX HD
71	CMT	1285	Spike HD
72	VH-1	1286	Syfy HD
73	MTV	1292	Comedy Central HD
74	HSN	1295	Bravo HD
95	Galavisión	1355	AMC HD
96	HSN	1359	LMN HD
97	Zap2It	1903	WOTF UniMás HD

TVIX Movie Player User Guide

We have over 150 movies available to watch on our main TV using the tvix media player. To watch a movie simply follow the steps below.

1 Turn on the media player by pressing the "power" button on the tvix remote control. The circular controller on the right of the player will start to flash blue and the LCD screen will show "Boot".

2 Now turn on the TV and select input HDMI   using the TV remote control.

3 When the player has booted, after approx 1.5 minutes, the tvix display will show "video" and on screen you should have a selection of "video" audio" or "photo".To select any icon use the direction keys on the remote control and the "OK" key for enter.

4   To watch movies select video and press the "OK" button. You should now have the three images(as below); Movies, Movies for children and Music. Select the required icon and press the "OK" button on the tvix remote.

Movies   Movies for children   Music

If you select movies, the next screen will list all the movies. Highlight desired movie and press 'OK'

You will then get a synopsis of the movie. To play highlight **Play** and press "OK". Movies take approx 20 seconds to load.

Hint: Chapter forward/back buttons will scroll through the pages of movies.

To listen to music simply browse the collection using the direction buttons and "OK" button.

Some films have DVD menus etc that need to be navigated, others just start the movie straight off.
NB There is no Parental control built into the player - you are responsible for the viewing of children.

PLEASE TURN OFF THE TVIX MEDIA PLAYER AND TV AFTER USE.

Bedrooms TV's

Please see guide above.

Please ensure that you always leave the remote controls next to the appropriate piece of equipment.

Twin rooms

Both Twin Bedrooms have a PS2 system for children's (or adults) enjoyment – these can also be used as DVD players